

HOW TO USE ...

PRISMA SIGNAL

91090, 91091, 91092, 91093, 91094, 91095, 91096



Remove the safety cap, which prevents unintentional spraying, with a pointed object (e.g. screwdriver).



PRISMA SIGNAL can be used in any position. It is also ideal for overhead workings.



The marking spray is weather resistant and with a range of approx. 150m also indispensable in forestry.



High opacity, 360° application and a rotating cap: That's PRISMA SIGNAL. Eh'klar!



Video:

<https://www.schuller.eu/en/p/prisma-signal2>

