

HOW TO USE ...

EASYSAND DS1220

02065



1 Attach the sanding disc

The holes of the sanding discs must be congruent with the holes on the sanding pad of the machine. Adhesion is achieved by the Velcro fastener.



2 Handle

Then screw on the handle.



3 Tube and bag

Attach the hose for the suction bag to the unit and to the suction bag itself.



4 Removal of abrasive material

There is an internal and an external dust particle extraction system. The 8-hole internal extraction system is designed for fine dust, so that optimal dust extraction is guaranteed on walls and ceilings.



5 It couldn't be easier

The very light machine is sucked onto the surface by a vacuum and enables work without tiring.



6 Spare Parts

Required spare parts are available under item number 9928..



Video:

<https://www.schuller.eu/en/p/easysand-ds1220>

